

REQ ITEM	PART NUMBER	BREAKOUT		DESTINATION OR DESCRIPTION	TO
		FROM	TO		
1	MWC22 (7)SJ8	1	13	J101	F101
2		1	15	J101	F102
3		17	15	S102	F102
4		17	13	S102	F101
5		17	2-B	S102	T101-3
6	MWC22 (7)SJ8	17	2-A	S102	↑ -1
7	MWC20 (7)U4	8	3-A	CR101 (YEL)	↓ -5
8	MWC20 (7)U94	8	3-A	CR101 (YEL)	↓ -6
9	MWC22 (7)U3	7-A	3-B	PS/TB-7	↓ -7
10		93	3-B		T101-8
11		92	3-B		C102 (+)
12		0	5		GRD
13	MWC22 (7)U90	7-A	19		F104
14	MWC20 (7)U2	7-A	16		C101 (+)
15		922	4	PS/TB-2	CR101 (RED)
16		90	8		CR101
17	MWC20 (7)U0	14	8	F103	GRD (CR101)
18	MWC22 (7)U0	14	8	F103	GRD (CR101)
19		0	8	F104	GRD
20		0	19	C101 (-)	C1011 (-)
21		0	4	C102 (-)	GRD
22		0	19	R106	C101 (+)
23		2	4	R106	C101 (+)
24	MWC22 (7)U922	12-A	4	J104-B	S101
25	MWC20 (7)U911	12-H	20	J104-H	J102-BB
26		11-7	6		↑ -8
27		922	6		↑ -14
28		933	6		↑ -19
29	MWC20 (7)U944	12-W	6		J102-EE
30	MWC24 (7)U0	12-U	19		GRD
31		964	6		J102-P
32		963	6		↑ -M
33		962	6		↑ -K
34		961	6		↑ -Y
35		1	6		J102-H
36		3	9-17		J103-18
37		94	10-A		↑ -A
38		95	9-17		↑ -17
39		6	9-21		↑ -21
40		9	10-E		J103-F
41		3	6		J102-FF
42		0	6		J102-HH
43		95	6		J103-I
44		6	6		J102-U
45		7	6		↑ -V
46		8	6		↑ -W
47		96	6		↑ -X
48		0	6		J102-Y
49		98	20		S101
50	MWC24 (7)U9	10-S	6		J102-AA
			6		J102-B
			6		J102-S