

REQ	ITEM	PART NUMBER	BREAKOUT		DESTINATION OR DESCRIPTION	TO
			FROM	TO		
	1	RG174/U	1	16	R192	TB101
	2		1	15	R191	
	3		1	14	R190	
	4		1	13	R189	
	5		2	13	R188	
	6		1	17	R187	
	7		1	16	R186	
	8		1	15	R185	
	9		1	14	R184	
	10		1	13	R183	
	11		2	13	R182	
	12		1	17	R181	
	13		1	16	R180	
	14		1	15	R179	
	15		1	14	R178	
	16		4	14	R177	
	17		4	13	R176	
	18		3	17	R175	
	19		3	16	R174	
	20		3	15	R173	
	21		3	14	R172	
	22		4	14	R171	
	23		4	12	R170	
	24		3	17	R169	
	25		5	16	R168	
	26		5	15	R167	
	27		6	15	R166	
	28		6	14	R165	
	29		6	12	R164	
	30		5	17	R163	
	31		5	17	R162	TB101
	32		7	16	R160	TB102
	33		8	16	R159	
	34		8	15	R158	
	35		8	14	R157	
	36		8	13	R156	
	37		7	17	R155	
	38		7	16	R154	
	39		8	16	R153	
	40		8	15	R152	
	41		8	14	R151	
	42		8	13	R150	
	43		7	17	R149	
	44		10	17	R148	
	45		10	16	R147	
	46		10	15	R146	
	47		10	14	R145	
	48		10	13	R144	
	49		9	17	R143	
	50	RG174/U	10	17	R142	TB102

S105A	PIN 10
S104A	10
S103A	10
S102A	10
S101A	10
S106B FRONT	3
S105A	8
S104A	8
S103A	8
S102A	8
S101A	8
S106A FRONT	11
S105A	6
S104A	6
S103A	6
S102A	6
S101A	6
S106A FRONT	9
S105A	4
S104A	4
S103A	4
S102A	4
S101A	4
S106A FRONT	7
S105A	2
S104A	2
S103A	2
S102A	2
S101A	2
S106A FRONT	5
S106A FRONT	3
S105A	11
S104A	11
S103A	11
S102A	11
S101A	11
S106B FRONT	4
S105A	9
S104A	9
S103A	9
S102A	9
S101A	9
S106B FRONT	2
S105A	7
S104A	7
S103A	7
S102A	7
S101A	7
S106A FRONT	10
S105A	PIN 5