

D.W. Carter

NAVSHIPS 92620

UNCLASSIFIED


RECEIVED  
NOV 7 1966  
ENGINEERING SERVICES

INSTRUCTION BOOK

for

**FREQUENCY SHIFT  
SIMULATOR  
MODEL FSS**

RECEIVED  
NOV 7 1966  
ENGINEERING SERVICES



RECEIVED  
NOV 7 1966  
ENGINEERING SERVICES

RECEIVED  
NOV 7 1966  
ENGINEERING SERVICES

THE TECHNICAL MATERIEL CORP.

Mamaroneck, N. Y.

Ottawa, Ontario

BUREAU OF SHIPS DEPARTMENT OF THE NAVY

NAVSHIPS 92620

INSTRUCTION MANUAL  
for  
FREQUENCY SHIFT SIMULATOR  
MODEL FSS

THE TECHNICAL MATERIEL CORPORATION  
MAMARONICK, NEW YORK

INSTRUCTION BOOK FOR MODEL FSS  
FREQUENCY SHIFT SIMULATOR

Table Of Contents

Section I, General Description

1. Purpose and Basic Principles
2. Description of the Unit
3. Reference Data
4. Tube Complement

Section II, Theory of Operation

1. General Description of the Circuits
2. Circuit Analysis


Section III, Installation and Operation

1. Installation
2. Operation
3. Initial Adjustments

Section IV, Maintenance

1. General
2. Emergency Measures
3. Preventive Maintenance
4. Calibration
5. Corrective Maintenance

REV. 10/11/61 MODEL 1531



FRONT VIEW, MODEL FSS

